

## CP-120 - Servo Drive



**Spare Part Number:** CP-120

**Net Weight:** 0.00kg

**Net Dimensions:** 0.00cm x 0.00cm x 0.00cm

**Technical Datasheet:** [Protected Link](#)

### Description

## CP-120 Servo Drive (This component need to be programmed in the factory)

**Please note:** This part is not a direct replacement for CP-260.

**Prior to ordering make sure you check what part is currently installed in your equipment.**

Electronic device that translates low-energy command signals from a controller into high-energy voltage and current delivered to a servo motor. The command signal can represent the desired position, velocity or torque. The servo drive monitors feedback on the motor and automatically adjusts its output to correct for differences between the commanded value and actual.

**NOTE:** This component need to be programmed in the factory.

R7D-BP04H

D2T / 400W

**Equipment reference**

| <u>Equipment Model</u>          | Ref. 1  | Ref. 2   | Ref. 3                                     |
|---------------------------------|---|--|--|
| <b>EVO 2 A</b>                  |   |  |  |
| <b>EVO 3 A</b>                  |   |  |  |
| <b>EVO 3 IP</b>                 | <b>Servo Drive 1</b> for M2 - Washout Brushes (on the Left) | <b>Servo Drive 2</b> for M4 - Washout Brushes (on the Right) | <b>Servo Drive 3</b> Brush Oscillati Left) |
| <b>Easy to Plate EVO 3 IP D</b> |   |  |  |
| <b>Easy to Plate EVO 3 IP I</b> |   |  |  |
| <b>EVO 4 IP</b>                 | <b>Servo Drive 1</b> for M2 - Washout Brushes (on the Left) | <b>Servo Drive 2</b> for M4 - Washout Brushes (on the Right) | <b>Servo Drive 3</b> Brush Oscillati Left) |
| <b>Easy to Plate EVO 4 IP D</b> |   |  |  |
| <b>Easy to Plate EVO 4 IP I</b> |   |  |  |
| <b>EVO 5 BP</b>                 | <b>Servo Drive 3</b>  | <b>Servo Drive 4</b>   | <b>Servo Drive 5</b>                       |
| <b>Easy to Plate EVO 5 BP D</b> |   |  |  |
| <b>Easy to Plate EVO 5 BP I</b> |   |  |  |
| <b>611 V2</b>                   | <b>M1</b>   | <b>M2</b>  | <b>M3</b>                                  |
| <b>620</b>                      | <b>M1</b>   | <b>M2</b>  | <b>M3</b>                                  |
| <b>621</b>                      | <b>M1</b>   | <b>M2</b>  | <b>M3</b>                                  |
| <b>830</b>                      | <b>M2</b>   | <b>M3</b>  |  |

**Catalogues/Families**

| Suitable for the following equipment models: |  |
|--|--|
| CLASSIC 3 P                                  |  |
| CLASSIC 4 P                                  |  |
| EASY TO PLATE EVO 4 IPD                      |  |
| EASY TO PLATE EVO 4 IPI                      |  |
| EASY TO PLATE EVO 5 BPD                      |  |
| EASY TO PLATE EVO 5                          |  |

|                            |  |
|----------------------------|--|
| BPI                        |  |
| EASY TO PLATE EVO 5<br>IPD |  |
| EASY TO PLATE EVO 5<br>IPI |  |
| EVO 2 A                    |  |
| EVO 3 A                    |  |
| EVO 4 IP                   |  |
| EVO 5 BP                   |  |
| EVO 5 IP                   |  |
| Spare Part Type            |  |
| Electrical Component       |  |
| Spare Part Group           |  |
| Others                     |  |
| Stock Type                 |  |
| Standard Stock             |  |

## Product Gallery

Servo Drive (100 - 400 W models)

