## CP-131 - Emergency stop switch



**Product Code:** CP-131

Weight: 0.00kg

**Dimensions:** 0.00cm x 0.00cm x 0.00cm **Technical Datasheet:** Protected Link

Manual: Protected Link

**Description** 

# **CP-131 Emergency Stop Switch**

The Emergency Stop Switch, also known as E-stop switch, emergency switch, kill switch, or emergency button is a fail-safe control switch that provides safety for the system and for the person using the system. The emergency stop switch must be highly visible in color, label (CP-132) and shape to operate easily in emergency situations. So the button must be red mushroom head with symbol of arrow, EMERGENCY or STOP. It needs a twist to release electrical contacts to allow system restart.

#### **Equipment Ref**

EVO 3 ELF Ref. BP1

EVO 3 EDLF Ref. BP1

EVO 3 IP Ref. **BP1** (Front left), **BP2** (Rear Left), **BP3** (Rear Right)

EVO 5 BP Ref. **BP1**, **BP2**, **BP3** 

EVO 5 BP D Ref. BP1, BP2, BP3, BP 4

#### EVO 5 BP I Ref. **BP1, BP2, BP3, BP 4**

610 Ref **BP1, BP2** 

620 Ref **BP1, BP2, BP3** 

621 Ref **BP1, BP2, BP3** 

830 Ref **BP0, BP1, BP2, BP3** 

810 Ref. **BP1, BP2** 

812 Ref. **BP1, BP2** 

### **Specification**

Suitable for the following equipment models:	
CLASSIC 3 P	1
CLASSIC 4 P	
EASY TO PLATE EVO 4	
IPD	
EASY TO PLATE EVO 4	
IPI	
EASY TO PLATE EVO 5	
BPD	
EASY TO PLATE EVO 5	
BPI	
EASY TO PLATE EVO 5	
IPD	
EASY TO PLATE EVO 5	
IPI	
EVO 2 A	
EVO 3 A	
EVO 3 EDLF	
EVO 3 ELF	
EVO 4 D	
EVO 4 DLF	
EVO 4 E	

EVO 4 EDLF	
EVO 4 ELF	
EVO 4 IP	
EVO 4 LF	
EVO 5 BP	
EVO 5 D	
EVO 5 DLF	
EVO 5 E	
EVO 5 ELF	
EVO 5 IP	
EVO 5 LF	
Spare Part Type	
Electrical Component	
Spare Part Group	
Others	
Stock Type	
Standard Stock	

### **Product Gallery**

