
CP-260 - Servo Drive

Spare Part Number: CP-260

Net Weight: 0.00kg

Net Dimensions: 0.00cm x 0.00cm x 0.00cm

Technical Datasheet: [Protected Link](#)

Description

CP-260 Servo Drive (This component need to be programmed in the factory)

Please note: This part is not a direct replacement for CP-120.

Prior to ordering make sure you check what part is currently installed in your equipment.

Electronic device that translates low-energy command signals from a controller into high-energy voltage and current delivered to a servo motor. The command signal can represent the desired position, velocity or torque. The servo drive monitors feedback on the motor and automatically adjusts its output to correct for differences between the commanded value and actual.

NOTE: This component need to be programmed in the factory.

R88D-KT04H-ALT

400W

Equipment reference

Equipment Model

Ref. 1

Ref. 2

Ref. 3

EVO 2 A

EVO 3 A

EVO 3 IP

Servo Drive 1 for M2 -
Washout Brushes (on the
Left)

Servo Drive 2 for M4 -
Washout Brushes (on the
Right)

Servo Drive 3
Brush Oscillati
Left)

**Easy to Plate EVO 3 IP I
D**

Easy to Plate EVO 3 IP I

EVO 4 IP

Servo Drive 1 for M2 -
Washout Brushes (on the
Left)

Servo Drive 2 for M4 -
Washout Brushes (on the
Right)

Servo Drive 3
Brush Oscillati
Left)

**Easy to Plate EVO 4 IP
D**

Easy to Plate EVO 4 IP I

EVO 5 BP

Servo Drive 3

Servo Drive 4

Servo Drive 5

**Easy to Plate EVO 5 BP
D**

**Easy to Plate EVO 5 BP
I**

611 V3

M1

M2

M3

Catalogues/Families

Suitable for the following equipment models:

| | |
|----------------------------|--|
| EASY TO PLATE EVO 4 IPD | |
| EASY TO PLATE EVO 4 IPI | |
| EASY TO PLATE EVO 5 BPD | |
| EASY TO PLATE EVO 5 BPI | |
| EASY TO PLATE EVO 5 IPD | |
| EASY TO PLATE EVO 5 IPI | |
| EVO 2 A | |
| EVO 3 A | |
| EVO 4 IP | |

| | |
|----------------------|--|
| EVO 5 BP | |
| EVO 5 IP | |
| Spare Part Type | |
| Electrical Component | |
| Spare Part Group | |
| Others | |
| Stock Type | |
| Standard Stock | |